

7'x14' Bownet Soccer Goal shown


Warning

- Keep fingers away from hinges and joints
- To be used for restraining Soccer Balls only
- Not a toy, do not climb on net
- Must be used with adult supervision
- Must be either Staked or Weighted down using BowBags (not supplied)
- Don't drag. To move net, use two people.




Play Anywhere. - Play NOW!


Assembly Instructions for 7'x14' and 6'6"x18' goals





1. Place double hinge on ground with Net spread out away from you. Pull one side of Frame up until it locks (clicks), then repeat on with other side .




2. Take half of Frame each, lowering them to the ground.




3. Open out side Frames of Net until hinge locks (clicking sound) Then pull up center hinge clicking both buttons.



4. Join Poles together (see A) Take 2 of the 4 poles and feed them into the orange 'front post' sleeves and slot them into the front tubes on the frame.




5. Next, take the 2 front Net Loops and place over the tops of the front Poles. Note: Pushing the poles towards each other will remove tension.



6 Place loops over poles using your pole holding Thumb.



7. Insert two rear Poles in frame. Repeat #6 with rear Loops.



8. Finally take black Loops (A) and place under Rubber Feet. (B) Stake the Net on Grass or use Bowbags on Turf (not supplied)

1 year limited Manufactures Warranty on Manufacturing defects only. 30 day money back guarantee. For a full description of Warranty-Guarantee-Terms & Conditions. See www.thebownet.com

Triad Sports Group LLC. 360 Cortez Circle Camarillo, California 93012 866.950.NETS